

DS500E & DS1000E

USER MANUAL



Copyright © 2025 Cold Jet, DK

All rights reserved. Printed in the Denmark.

DUE TO CONTINUED PRODUCT DEVELOPMENT THIS INFORMATION MAY CHANGE WITHOUT NOTICE. THE INFORMATION AND INTELLECTUAL PROPERTY CONTAINED HEREIN IS CONFIDENTIAL BETWEEN COLD JET AND THE CLIENT AND REMAINS THE EXCLUSIVE PROPERTY OF COLD JET. IF YOU FIND ANY PROBLEMS IN THE DOCUMENTATION, PLEASE REPORT THEM TO US IN WRITING. COLD JET DOES NOT WARRANT THAT THIS DOCUMENT IS ERROR-FREE.

NO PART OF THIS PUBLICATION MAY BE REPRODUCED, STORED IN A RETRIEVAL SYSTEM, OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC, MECHANICAL, PHOTOCOPYING, RECORDING OR OTHERWISE WITHOUT THE PRIOR WRITTEN PERMISSION OF COLD JET.

THIS MANUAL REFLECTS THE PRODUCT CONFIGURATION AS WAS CURRENT AT THE TIME OF ITS WRITING. AN ITEM'S DISPLAY IN THIS MANUAL DOES NOT GUARANTEE THE ITEM'S AVAILABILITY AT ANY TIME IN THE FUTURE. IMAGES SHOWN ARE FOR REPRESENTATION PURPOSES ONLY. PRODUCTS MAY VARY FROM THE IMAGES DISPLAYED. COLD JET IS NOT LIABLE FOR TYPOGRAPHICAL ERRORS OR CHANGES TO SPECIFICATIONS PRESENTED.

CONTENT

INTRODUCTION	4
• About the DS500E and DS1000E direct slice machines	4
SYSTEM DESCRIPTION	5
• Functional description	5
• System identification	6
• Supplier responsible for the equipment	6
• Technical Data	7
SAFETY REGULATIONS	10
• General measures	10
• Personnel qualifications	10
• Security and risk	10
• Danger of suffocation	11
• Static electricity	11
• Danger of congelation	12
• Pinch point hazard	12
• Wear protective gloves	12
SAFETY OPERATION	13
• Emergency stop	13
• Machine safety	13
• Liquid CO2 leakage	13
• Stop production	13
• Daily checkup before start-up	13
MACHINE STRUCTURE	14
MACHINE CONTROLS	16
• Alarms	26
• Shut down	28
REPAIR AND WARRANTY	33
• Repair	33
MAINTENANCE	33
• Degassing system:	33
• Safety device replacement intervals	33
TERMS OF WARRANTY	34
• Cleaning the machine	34
INSTRUCTION – UNPACKING AND PREPARATIONS BEFORE INSTALLATION	36
• End of life for the machine	38



INTRODUCTION

This manual should be kept with the machine and be readily accessible for operation and maintenance. This manual contains information about the safety, the operation, and the maintenance of the machine.

The graphics used in this manual may show machine details that may be different than the actual machine. Components of the machine may have been removed for illustrative purposes or the continuing improvement of the machine's design may cause changes that are not included in this publication.

The owner of this machine is responsible for verifying the operator of this machine is properly trained and understands the contents of this manual.

About the DS500E and DS1000E direct slice machines

The DS500E and DS1000E direct slice machines from Cold Jet presents a state-of-the-art dry ice machine with features for easy operation, swift production shifts, and high-capacity performance.

The direct slice machines produce high-quality dry ice slices. These are made and prepared ready directly in the machine, placed on top of the conveyer. This means that no additional handling of the dry ice slices are needed.

The machine parts are protected by an enclosure, which reduces the noise level to a minimum (below 75 dB(a)). The direct slice machines provide a direct slice system. The source of raw material for the production of slices is liquid carbon dioxide preserved at low temperatures in a storage tank.

The control system of both the DS500E and DS1000E are, based on Beckhoff Industrial PC and HMI system, that offers maximum functionality and a user-friendly interface.



SYSTEM DESCRIPTION

This operator manual covers both the DS500E and the DS1000E operating instructions. The main parts are described in the machine controls section.

Functional description

The main function of the DS machines is to produce dry ice slices directly to a conveyer from liquid carbon dioxide. This is done by a sequence of operations executed by the Beckhoff IPC. The main steps during normal production are as follows and refer to PI diagram:

- 1. Start-up**
- 2. Production**
- 3. Standby**
- 4. Shut down**

The DS machines produces a slice in the requested thickness. The thickness is determined by incoming CO₂ and adaptive learning about the thickness. This means that over time the program will adjust so the thickness is always right. Slices are dropped from the production unit below the machine. Either the slices are dropped from the production unit when a sensor is activated, or an external input.




The machine is designed with dehumidifier to mitigate humidity inside the machine.




Color detection of the lighthouse

Green:	Machine is ready and there are no alarms (error messages).
Yellow:	Machine has been paused.
Red:	Machine out of operation due to an alarm (error message).

System identification

System is marked with:

DS500E			
Machine no.:		Weight:	
2A0684		1350Kg / 2977lbs	
Serial no.:	Year:	Power:	
2023-06-31	2023	3x400VAC+N+PE, 50HZ, 40A	
P max. CO2:	P max. Air:		
18Bar/260Psi	10 Bar/ 145Psi		
			
Industrivej 68 - DK-6740 Bramming - www.coldjet.com			

DS1000E			
Machine no.:		Weight:	
2A0674		1820 Kg / 4012 lbs	
Serial no.:	Year:	Power:	
2023-06-30	2023	3x400VAC+N+PE, 50HZ, 75A	
P max. CO2:	P max. Air:		
18 Bar/260 Psi	10 Bar/ 145 Psi		
			
Industrivej 68 - DK-6740 Bramming - www.coldjet.com			

Supplier responsible for the equipment

Cold Jet ApS
Industrivej 68
DK-6740 Bramming
Denmark
Phone: +45 75 56 15 00
Fax: +45 75 56 15 09
Homepage: www.coldjet.com

Technical Data

Rated output:

DS500E: Up to 500 kg/hr (1,102 lb/hr)

DS1000E: Up to 1,000 kg/hr (2,204 lb/hr)

Slice size:

125 x 125 x 15 mm (5 x 5 x 0.5 in) to 125 x 125 x 60 mm (5 x 5 x 2.3 in)

Inlet liquid CO₂ pressure:

Liquid CO ₂ Supply System	DS500E	DS1000E
Supply Pressure (Min-Max)	13-18 bar -30°C to -20°C (189-261 psi -22°F to -4°F) Optimum performance range 15-16 bar -24°C to -26°C C (232-290 psi -11°F to -15°F)	
Supply Pressure Range	+/- 1.0 bar (14.5 psi)	
Supply Pressure (Recommended PBU Setting)	16.5 bar (240 psi)	
Flow Rate - Minimum	1000 kg/hr (1984 lb/hr)	2200 kg/hr (4850 lb/hr)
Pelletizer Design Pressure / PRV setting	27.6 bar (400 psi)	
Liquid CO ₂ Line Size Recommended ID	25 mm (0.98 in)	25 mm (1.0 in)
Liquid CO ₂ Connection at Pelletizer	EU: 3/4-inch BSP / US: 3/4-inch NPT	
Liquid CO ₂ Line Insulation	Min. 75mm (3.0 in) Industrial Insulation - (Urethane Foam - PVC/Alu jacket)	

Liquid CO₂ dryness fraction:

The water content should not exceed 35 ppm and should not be less than 5 ppm – or equivalent to a dewpoint temperature of -66°C to -51°C (-86.8°F to -59.8°F).

NOTE:

The liquid CO₂ supply must be completely free of oil and must have a minimal purity of 99.9%.

Liquid CO₂ supply pipe:

Internal diameter 20 mm (0.8 inch), very well insulated with a minimum number of bends and fittings.

NOTE: If over 20 m (65.6 feet) in length, use an internal diameter of 25 mm (1 inch).

Power supply:

The direct slice machine requires a three-phase power supply. The power source must be grounded:

- For machines in the US: use a Solidly Grounded WYE Source.
- For machines outside US: use a TN-S grounding acc. to IEC 60364.
- All phases must be balanced, and voltages must be within $\pm 10\%$.

Electrical Service & Supply	DS500E	DS1000E
Standards	EN 60204-1 & IEC 61439-2	
Voltage AC/ Frequency (EU 50Hz)	3 x 400 V AC + N + PE / 50Hz	
Number of phases	3	
Short Circuit Current, Min / Max	0,5 kA / 10 kA	
Upstream Fuse Max	50 A	100 A
Rated Current (Imax)	40 A	75 A

Machine dimensions:

Weights and Dimensions	DS500E	DS1000E
Shipping Weight Transport (Includes Pallet/Crate)	1340 kg (2954 lb.)	1830 kg (4034 lb.)
Shipping Crate Dimensions (LxWxH)	1640 x 1430 x 2650 mm (64.5 x 56.5 x 104 in)	2200 x 1440 x 2650 mm (86.5 x 56.7 x 104 in)
Machine Weight	1310 kg (2888 lb.)	1800 kg (3968 lb.)
Machine Dimensions (LxWxH)	1330 x 1330 x 2410 mm (52.5 x 52.5 x 95 in)	1890 x 1330 x 2410 mm (74,5 x 52,5 x 95 in)

Noise level: below 75 dB(a)



SAFETY REGULATIONS

General measures

The DS500E & DS1000E manual contains instructions for starting up, operating, and servicing the machine. The operator must follow all instructions in this manual. The owner must make sure that the operator understands the contents of this manual and follows its guidelines and safety regulations.

Personnel qualifications

Employees, who are in charge of installation, operation, service, and maintenance must be adequately trained to install and operate this machinery.

If the employees do not possess sufficient knowledge, they must be instructed and trained properly. If necessary, this can be arranged in cooperation with the manufacturer of the machine.

The owner of the machine shall make sure that the operator, who is to work with the PR750H, fully understands the importance of studying the contents of this manual and comply with the SAFETY REGULATIONS described on the following pages as well as those placed on the machine.

Contraindications

Cold Jet Machines are designed to operate for long periods of time. The machine is designed with an HMI that enables the operator to act upon errors that might occur during operation. The machine should only be operated with the doors closed. Entering the machine, for service purposes etc. should be done in a way that allows the Contained CO₂ to reach a safe level and the temperature to fall for certain areas.

Machines with moving parts inside can cause injury, therefore they are designed with door switches that disable the machines from running when opened/activated.

Security and risk

The DS500E and DS1000E are designed to comply with the EC Declaration of Conformity for Machinery. Therefore, using the machine does not pose a risk to the operator when the instructions in this manual are followed.

It is important that the operator follows the safety signs posted on the machine and the safety regulations described in this manual and that the operator reads and understands the contents of this manual before starting up the machine.

Installation must be carried out according to the instruction "Pre-installation Guide DS500E and DS1000E".

The machine may only be installed by authorized personnel with knowledge of the Council Directives BT 2014/35/EU and EMC 2014/30/EU (or similar directives in other parts of the world).



Danger of suffocation

Dry ice pellets are CO₂ in solid form. At ordinary atmospheric pressure, CO₂ can only exist in this solid form at temperatures of -79°C (-110°F) or lower. Therefore, during dry ice production, the CO₂ will immediately be heated and thus transform from solid form into gas form.

Please note:

Since the specific gravity of CO₂ is higher than that of ordinary atmospheric air, the air with its contents of oxygen will be replaced by CO₂ if the dry ice production is taking place in small or insufficiently ventilated rooms.



Therefore, please note the following:

1. Low CO₂ concentrations (3-5%) may cause headaches and rapid breathing.
2. CO₂ concentrations of (7-10%) may cause headaches and nausea and may result in unconsciousness.
3. Higher CO₂ concentrations will result in unconsciousness and suffocation.

High CO₂ concentrations may result in unconsciousness due to the displacement of oxygen. Therefore, always provide sufficient ventilation of the working area, and avoid producing dry ice in small rooms.



Static electricity

Dry ice can cause electrostatic discharges. However, the equipment is bonded to the ground to minimize electrostatic discharge, and the warning sign is meant to instruct the operator to avoid placing the equipment in rooms containing explosive gasses.

It is recommended to use a plastic shovel in the dry ice container.

**Danger of congelation**

CO₂ in solid form has a temperature of -79°C
/-110°F or lower at atmospheric pressure and can therefore cause serious congelation injuries.

IMPORTANT!

The dry ice is extremely cold, therefore, do not touch parts of the machine, which are in direct contact with the dry ice without wearing appropriate protective clothing and gloves.

**Pinch point hazard**

If the plexiglass covers in front of the extruder plates are removed, the operator will be exposed to pinch point hazards.

**Wear protective gloves**

While working with the conveyor system, the operator must wear protective gloves to avoid contact with the dry ice or with parts of the machine which are in direct contact with the dry ice.

SAFETY OPERATION

Emergency stop

All equipment is connected to the general emergency system.

When an emergency-stop device is activated, all components located in the emergency zone will be disconnected from their power source.

Machine safety

There are machine safety measures in the following areas:

- Extruder unit

In these areas, protective covers are in place.

The covers are provided with locking screws to deter removal.

Required performance level PLr = c Implemented in category = Cat3.

There is a danger of congelation/frost bite by touching machine parts cooled down by dry ice.

To prevent congelation the entire machine enclosure is provided with locks that require special tools to open.

Liquid CO₂ leakage

If liquid CO₂ is leaking from any point of the CO₂ pipe system, the CO₂ supply must be stopped immediately. Localize the leakage and repair.

Stop production

1. The machine is stopped by pressing the "Start / Stop" button.

NOTE: This will activate the shutdown procedure.

2. The CO₂ valve on the machine inlet will automatically close. It is recommended to close the manual valve on the mounting kit before leaving the machine unused for a longer period of time.
3. Cut off the main electric supply.

NOTE:


Do not shut off the main switch on the cabinet inside the machine before the inlet CO₂ pressure is ZERO. The CO₂ pressure can be checked on the "Process values" page.

Daily checkup before start-up

1. Check the pipe system for leaks.
2. Check the operation time since last service.


MACHINE STRUCTURE

DS500E



1. Electrical cabinet
2. HMI screen
3. Dehumidifier
4. Processing units
5. Heat exchangers
6. Pneumatic
7. Light tower

DS1000E



1. Electrical cabinet
2. HMI screen
3. Dehumidifier
4. Processing units
5. Heat exchangers
6. Pneumatic
7. Light tower

MACHINE CONTROLS

This section describes how the system is operated from the HMI.
This document can be used as a reference work with references to the various sections.

The numbers shown on the screen must not be taken as current setting values on the system.



Symbol is used to make the user aware of some important information, or to warn the user about something.



The symbol is used to draw the user's attention to some information that may be useful to know.

Navigating the HMI panel



Header

1	2	3	4	5	6	7
<ol style="list-style-type: none"> 1. Auto- / Manual-mode (Here it is possible to see the state, and change the state, if logged in). 2. Cold Jet logo / Alarm banner. – If any alarms, they will also appear here. 3. Language change. 4. ADS State – Twincat. 5. ADS State – PLC program. 6. User login. 7. Date & time. 						


ADS State

Twincat			PLC program		
		Unknown			Unknown
		Run (Twincat is in state run)			Run (program is in state run)
		Stop (Twincat is in state Stop)			Stop (program is in state Stop)
		Config (Twincat is in state config)			Config
		Exception (Twincat is in state exception - error)			Exception

Navigation Bar

	1	1. Back – Will navigate the user back to the previous screen.
	2	2. Home – Will navigate the user to the main screen.
	3	3. Process Variables – Will guide the user to the PI screen, where all essential control modules are prominently displayed.
	4	4. Settings – Requires login. Will Navigate the user to the settings page, consisting of different machine settings.
	5	5. Alarms - Will Navigate the user to the alarm page, with current alarms.
	6	6. Hardware - Will Navigate the user to a hardware overview/ topology, for everything connected on the EtherCat.
	7	7. Log & Information – Will navigate the user to a “log” page, where various activities and information are recorded.


Certain navigation buttons feature sub-menus that will be displayed beneath the navigation bar, as exemplified below in the case of the alarm page.




Process variables page

On the Process Variables page, you can view all relevant process variables such as temperature, pressure, and piston position. These variables are displayed in a dedicated PI diagram that aligns with the machine layout.

Please note that the dehumidifier and instrumental air settings can be found in the 'Other Setpoints' page, which is a sub-menu accessible from the Process Variables page.




The Process Variables page is also where you can access all the different setpoints. Each setpoint is organized based on the respective process instrument it belongs to. For instance, to access the setpoints for the G01.G01 piston, you simply click on the G01.G01 piston itself.



Login

When you click the "User" button and then select "Switch User," a popup screen will appear.

- On this screen, you can choose a user and enter the correct password.
- To log out, you can click the "User" button and then select "Logout."




User levels:

Permissions:

User: Operator	Can view everything, start / stop the system, and choose between the different receipts.
User: Receipt Change	Same as 'Operator' + <ul style="list-style-type: none">- Edit the receipts.
User: User	Same as 'User' + <ul style="list-style-type: none">- Run control modules in manual.


Manual control

To control a component manually, begin by logging in. Then, switch the entire system to manual mode, and after that, you can select the specific component, which will prompt a popup menu to appear.




During manual operation, it is the operator's responsibility to ensure that the process and equipment are not damaged.

Below, you can find examples of the menus that will appear when specific components are selected:




Automatic control

When pressing start the system will start as according to the setpoints and the automated behavior.




Setpoints

Within the Process Variables page, you'll find a range of setpoints. As previously mentioned, these setpoints are organized based on the specific process they are associated with. To access the setpoints for the piston, simply click on the piston. In the same way, you can access the setpoints for the injection valve by selecting it, and the various heating setpoints are accessible by clicking on each individual heating element.



Additionally, there are a few setpoints located on the 'Other Setpoints' page. Here, you can find setpoints for instrumental supply air and the dehumidifier.




For the functionality of the system, all setpoints require you to be logged in! Generally, changes to setpoints are at your own risk and may affect the functionality of the system!

Various setpoints


Here you will find a description for various setpoints.


G01 - G01 - Settings	
Setpoint - Inlet time:	4.00 s
Setpoint - Inlet time - Build pillow:	3 s
Process variable - Inlet time:	
Setpoint - Delay afterfill:	0 s
Setpoint - Position eject:	370 mm
Setpoint - Max pressure move G1:	1 Bar
Setpoint - Max inlet pressure:	4.5 Bar
Setpoint - Max purge time:	120 s
Setpoint - General time out:	500 s

Name:	Explained:
Setpoint – Inlet time:	Duration of injection time.
Setpoint – Inlet time – Build pillow:	Duration of building pillow at startup.
Setpoint – Delay afterfill:	Delay timer after filling is completed and before pressing slice.
Setpoint - Position eject:	Piston position for ejection.
Setpoint – Max pressure move G1:	Max pressure before we move piston M2
Setpoint – Max Inlet pressure:	Max inlet pressure during making snow. If reached the process will continue even though 'Setpoint – Inlet time' was reached.
Setpoint – Max purge time:	If reached an alarm will occur.
Setpoint – General time out:	If reached an alarm will occur.

G01 - G01 - Q1_M1		Name:	Explained:
Opening degree of valve:	0 Pct	Setpoint for opening degree in automatic:	The opening degree of the snow valve M1 during injection.
Setpoint for opening degree in automatic:	40 Pct		
Manual Movement:			
			

G01 - G01 - TT4		Name:	Explained:
Process variable:	0 °C	Setpoint for heat control:	The temperature setpoint for the heating elements associated with the temperature transmitter.
Setpoint for heat control:	10 °C		


G01 - G01		Name:	Explained:
KP - Proportionality const. P. - for the PID regulator Tn - Integral part [sec]. - for the PID regulator		Kp:	P (Proportional) gain in the PID regulator
		Tn:	I (Integral) gain in the PID regulator

EP01 - Dehumidifier		Name:	Explained:
Start of dehumidifier 0 50 Pct Stop of dehumidifier 30 Pct 			
High humidity warning in machine 70 Pct			
Start of dehumidifier			If the humidity in the machine reaches this value or exceeds this value, the dehumidifier will activate.
Stop of dehumidifier			If the dehumidifier is activated and the machine's humidity level drops below this value, the dehumidifier will stop.
High humidity warning in machine			Humidity above this value will activate a warning.

CA01 - Air supply		Name:	Explained:
Low Pressure for Instrumental air - alarm: 5 4.00 Bar Low Pressure for Pneumatic seal - alarm: 3 0.50 Bar			
Low pressure for instrumental air – alarm:			If the pressure for the instrumental air drops below this value, an alarm will trigger, and the machine will stop.
Low pressure for pneumatic seal – alarm:			If the pressure for the pneumatic sela drops below this value, an alarm will trigger, and the machine will stop.


Alarms

When system alarms, warnings, or messages occur, the three most recent and critical ones are displayed in the screen header. To acknowledge an alarm, the user needs to access the alarm page, which can be done either through the navigation bar or by pressing on the displayed alarms in the header.



Alarm page

The alarm page displays all currently active alarms, warnings, and messages. For each alarm, you can observe several key details: Time (1) indicating the time and date at which the alarm occurred, the alarm message (2) describing the nature of the alarm, and the alarm fb (3) indicating the origin within the program where the alarm occurred. All alarms are acknowledged by pressing the button (4).



Alarm history

Alarm log shows all alarms, warnings and messages which has occurred.

Auto Mode

1

0

0

2023-10-10-11:00:16.608

PV Less Than SP

CA01.TP1

en-US

TwiniCAT

PLC 1

ColdJet

11:14:33 AM

10/10/2023

Alarms > Alarm history

Time	Message	Alarm FB
2023-10-10-11:00:16.608	PV Less Than SP	CA01.TP1
2023-10-10-07:42:30.289	PV Less Than SP	CA01.TP2
2023-10-10-07:42:30.289	PV Less Than SP	CA01.TP1
2023-10-10-07:27:42.227	MCB	EP01
2023-10-10-07:27:41.727	PV Less Than SP	CA01.TP2
2023-10-10-07:27:41.727	PV Less Than SP	CA01.TP1
2023-08-23-13:37:59.211	Maximum heat	G02.G01.E1
2023-08-23-13:35:23.438	Maximum heat	G01.G02.E1
2023-08-23-13:35:14.686	AlarmID=17744	G02.G01.G1_M2
2023-08-23-13:35:14.686	AlarmID=17744	G01.G01.G1_M2
2023-08-23-13:35:14.676	AlarmID=17744	G02.G02.G1_M2
2023-08-23-13:35:14.435	AlarmID=18000	G01.G01.G1_M3
2023-08-23-13:34:24.264	AlarmID=18000	G01.G01.G1_M3
2023-08-23-13:32:49.631	AlarmID=18000	G01.G01.G1_M3
2023-08-23-13:05:10.501	Max Purge time	G02.G01
2023-08-23-13:05:10.431	Max Purge time	G01.G02
2023-08-23-09:33:56.754	PV Less Than SP	CA01.TP1
2023-08-22-23:12:13.183	State operational	Safety connection lost!
2023-08-22-23:12:13.133	Invalid data - Check hardware	Safety connection lost!
2023-08-22-13:18:09.947	PV Less Than SP	CA01.TP2

Save Log

Back

Home

Process Variables

Settings

Alarms

Hardware

Log & Information

Alarm history


Receipt change and deactivation of process units

To perform a receipt change or deactivate a cylinder, first login as Receipt change or higher (1).

To perform a receipt change, press the slice bottom at the bottom of the screen (2).


To deactivate a process unit, press the gear bottom at the bottom of the screen (3).

From both bottoms, you will go to a page where receipt change can be performed and process units can be deactivated.




At the receipt change page, the density can be selected. The density can be set to low, middle or high.


It is also a process unit that can be set to off.




If off is selected at the page before, when going to "Home" the selected process unit will not be active, showing by not be ticked in the box (1).




Logging in as userlevel 'user' (1), press the bottom 'automode' to change it to 'manual' mode (2).
In order to run with the individual motors, press the bottom 'process variables' (3).



Select the servo motor that should be operated manually.




Press the process unit and use the arrows in the zoomed in screen. The arrows will move the servo motor.



Shut down

To safely shut down the system, follow these steps:

1. Log in with a 'User' or higher privilege.
2. Switch the system to 'Manual mode.'
3. Afterward, a 'Shut down machine' button will appear in the lower right corner.
4. By clicking 'Continue,' the CPU will power off in 10 seconds.



Log and Information

On the log page, users can access information about the system's start and stop times, as well as other messages.

Auto Mode

Cold Jet

en-US

TwinCAT

PLC 1

User

11:52:12 AM
10/10/2023

Log & Information

	Batch	Day Start	Time Start	Time Stop	Produced	Msg	Stage G01
1	344	2023-08-23	13:35:14	13:35:14		Alarm , fbg01.fbg01.fbg1_M3	G01=S0100, G02=S0120
2	343	2023-08-23	13:33:07	13:34:24		Alarm , fbg01.fbg01.fbg1_M3	G01=S1620, G02=0A04_Produktion
3	342	2023-08-23	13:24:22	13:32:49		Alarm , fbg01.fbg01.fbg1_M3	G01=S1630, G02=S1400
4	341	2023-08-23	13:08:02	13:15:47		User Input	
5	340	2023-08-23	13:05:35	13:06:18		User Input	
6	339	2023-08-23	13:03:03	13:05:10		Max_PurgeTime , fbg01.fbg02	G01=S0410, G02=S0500
7	338	2023-08-22	13:22:43				
8	337	2023-08-22	13:22:19	13:22:25		User Input	
9	336	2023-08-22	13:20:05	13:20:13		User Input	
10	335	2023-08-22	13:18:28				
11	334	2023-08-22	13:17:09	13:17:15		PV_Less_Than_SP , fbgA01.fbgTP2	G01=S0200, G02=S2500
12	333	2023-08-22	13:16:35	13:16:41		User Input	
13	332	2023-08-22	13:11:38	13:11:44		User Input	
14	331	2023-08-22	13:11:19	13:11:26		User Input	
15	330	2023-08-22	13:09:20	13:09:20		Alarm , fbg01.fbg01.fbg1_M3	G01=S0100, G02=S0100
16	329	2023-08-22	13:08:54	13:08:54		PV_Less_Than_SP , fbgA01.fbgTP1	G01=S0100, G02=S0100
17	328	2023-08-22	13:03:32	13:03:37		Max_ActionTime , fbg01.fbgW01.fbgQ1	G01=S0140, G02=S0140
18	327	2023-08-03	19:33:56	19:45:02			
19	326	2023-08-03	19:33:45	19:33:51			
20	325	2023-08-03	19:33:38	19:33:44			
21	324	2023-08-03	19:33:24	19:33:38			
22	323	2023-08-03	19:31:05	19:33:17			
23	322	2023-08-03	19:30:09	19:31:03			

Save Log

Back

Home

Process Variables

Settings

Alarms

Hardware

Log & Information

Device Information

Device Information

On the Device Information page, users can access various details about the device/ CPU, and machine information. Additionally, the Teamviewer ID is also displayed and software versions.

Auto Mode

Cold Jet

en-US

TwinCAT

PLC 1

User

11:53:09 AM
10/10/2023

Log & Information > Device Information

Device Information:

Target Type : PC-WIN 10.0

Hardware model :

Hardware Serial no :

Hardware Version : 0.0

Hardware Date : 0.0.00

Hardware CPU : INTELx86

Image Device :

Image Version :

Image Level :

Image OS Name : Windows 10 Enterprise

Image OS Version : 10.0

TwinCAT Version : 3

TwinCAT Revision : 1

TwinCAT Build : 4024

TwinCAT Level : CP

AMS NetID : 169.254.184.200.1.1

Machine Information:

Machine No :

Serial No :

Cabinet No :

Machine Type :

Machine Info :

Customer :

Project No :

HMI software ver. : TE2000.1.0.1.3 (2023-08-03)

Main Software ver. : Ver. TC3.00.5 (2023.07.24)

Line Software ver. : Ver. TC3.00.06 (2023.07.24)

TeamViewer ID : 0

Back

Home

Process Variables

Settings

Alarms

Hardware

Log & Information

Device Information

REPAIR AND WARRANTY

Repair

The repair/replacement of the following parts must be made by qualified personnel:

- Filter for the liquid CO₂.
- Degassing filter.
- Processing unit.

When making repairs/replacements, use only original Cold Jet spare parts.

MAINTENANCE

Inspections to be carried out weekly:

Degassing system:

Check the degassing system. Check the degassing for snow particles at the CO₂ outlet (can only be done when dry ice is being produced)

Snow particles at the CO₂ outlet indicate that the degassing filter is damaged. Replace the filter and gasket as described under in this manual.

Inspections to be carried out every 400 hours / 3 months.

Safety device replacement intervals

The expected lifetime is 20 years or 100,000 couplings on electromechanical components (contactors and relays) whichever is the grater.

TERMS OF WARRANTY

In order to comply with the terms of the warranty, and for safety reasons, repairs other than those stated above require relevant tools and equipment and therefore must always be made either by a Cold Jet technician or by the owner's qualified personnel who has been trained by Cold Jet in the repair and maintenance of Cold Jet dry ice blasting and dry ice production machines and accessories. Beyond the necessary knowledge, the person concerned must have appropriate tools and equipment, as well as the auxiliary materials required, at their disposal.

The liability of the manufacturer under the terms of the CE endorsement as regards to safety may become **invalid**:

- If repairs are made using non-Cold Jet spare parts.
- If repairs are made by unqualified personnel.
- If repairs are unsatisfactory due to lack of relevant tools and equipment.

In such cases, the liability of the manufacturer will be solely confined to any manufacturing faults/errors made prior to the machine being delivered and before repairs/replacements have been made.

Cleaning the machine

The following steps are necessary when the DS500E or DS1000E needs to be cleaned.

- Disconnect the power.
- Protect all electronic equipment.
- Protect the holes at the bottom of the machine.

All surfaces can be cleaned with a degreaser and acid-free oil. If the bottom of the machine contains water this can be swiped up.

If cleaning with high pressure measures should be taken to ensure that components does not take damage, with lower pressure, distance to the machine or other preventive measures.



INSTRUCTION – UNPACKING AND PREPARATIONS BEFORE INSTALLATION

Your new machine has been assembled as one unit. In order to avoid damages during transport, the machine has been bolted onto the transport pallet.

Unpacking and Examination for Transport Damages

1. Examine the shipping container for any damages that may have occurred during transport.
2. Remove the machine, box(es) that contain accessories, and discard packing material, braces, and ties.
3. Examine the machine for any external damage that may have occurred during transport.
4. Open the cabinet doors of the machine and examine the machine for any internal damage that may have occurred during transport.
5. Open the front cabinet door and locate the box on the machine floor containing user documentation, optional spare parts kit(s), and other accessories.

Requirements on the Environment Surrounding the direct slice machines

- The DS500E and DS1000E must be sheltered from wind and weather.
- The ambient temperature must be min. +5°C (+41°F).

How to Lift/Transport the PR750H

Drawing no. A1

Always transport the machine in the upright position using a forklift. Pick up the machine from the side with the forks fully engaged and adjusted to the maximum width (refer to "Figure 1: Transporting and Lifting the Machine."). please give extra attention to the bottom part of the machine, as the truck can damage the machine if the forklifts fork hit the tube or the pressure unit output.

- Always lift the PR750H according to the lifting Instructions in this manual.
- Lifting over people and animals is prohibited.
- Always use a forklift truck to transport the DS500E or DS1000E.
- Transport the machine upright.
- Make sure that the forks are long enough to fully engage the DS500E or the DS1000E.
- Always check that the forks are adjusted to proper width to not hit the tube or the pressure units below when lifting.

Floor Characteristics and Minimum Clear Distances

Drawing no. A2

- The DS500E or the DS1000E must be placed on a horizontal concrete floor with an adequate load-carrying capacity, free from crack formation and suitable for bolting the DS500E or the DS1000E to it.
- The minimum clear distances must be observed to provide sufficient space for opening the cabinet doors and servicing.

Preinstallation

Before the pelletizer can be installed, the owner/operator must prepare the site for installation and operation. It is the owner's responsibility to verify that all the necessary preparations have been made for the installation site and meet the specifications and guidelines detailed in the appendix: Pre-Installation Guidelines & Checklist. This may include but is not limited to:


- Providing an indoor space with standard industrial flooring.
- Installing a liquid CO2 tank and supply pipeline system up to the connection point at the pelletizer.
- Installing a gaseous CO2 exhaust pipeline from the pelletizer to vent at a safe position.
- Installing a power supply that is sufficient and up to code.
- Providing proper room ventilation and other CO2 safety measures.
- Determine which options and other manufacturing accessories to add/prepare for maximizing production performance and capabilities.

The owner is responsible for transmitting the specifications in this publication to other third-party contractors involved in pre-installation preparations of the site. Failure to properly prepare the site may delay the installation and/or optimal performance of the pelletizer. The graphics used in this manual may show pelletizer details and installation components that may be different than what is actually used. Components may have been removed for illustrative purposes or the continuing improvement of the pelletizer's design may cause changes that are not included in this publication.

Installation of the machine

The installation of the DS500E or DS1000E must be carried out by a Cold Jet service technician, or by a technician approved by Cold Jet. In most cases integration is needed to properly function with the conveyor below the machine.

DRAWING No. A1




Correct Handling of a DS500E or DS1000E

Forklift Requirements	DS500E	DS1000E
Load Capacity	2000 kg (4409 lb.)	2500 kg (5512 lb.)
Fork Length (Minimum)	2 m (79 in)	2 m (79 in)

Use a forklift to move the DS machines. Beaware of the output holes below, as the forklift should NOT lift on these spots. On DRAWING No. A1 these are maked with red.

DRAWING No. A2



End of life for the machine

When the DS500E or DS1000E is at the end of its life, the following steps are required.

- Disconnect the power
- Disconnect the CO² in
- Disconnect the remaining connections

The materials must be disposed of according to the jurisdictional rules and regulations for proper disposal.